

SPARE PARTS LIST

MODEL NO. BO5031

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	265995-6	TAPPING SCREW 4X18	3	
002	450810-9	TOP COVER	1	
003	265995-6	TAPPING SCREW 4X18	2	
004	645105-5	NOISE SUPPRESSOR	1	
005	687052-4	STRAIN RELIEF	1	
006	682502-4	CORD GUARD 8-85	1	
007	665383-1	POWER SUPPLY CORD 1.0-2-2.0	1	
008	191962-4	CARBON BRUSH CB-419	1	
009	643995-0	BRUSH HOLDER	2	
010	654532-5	TERMINAL BLOCK 1P	1	
011	651527-9	SWITCH	1	
012	424039-3	SWITCH COVER	1	
013	450809-4	MOTOR HOUSING	1	
014	866159-1	BO5031 NAME PLATE	1	
015	633674-8	FIELD 240V	1	
016	266147-2	TAPPING SCREW 4X55	2	
017	210017-7	BALL BEARING 607DDW	1	
018	681652-2	INSULATION WASHER	1	
019	515734-7	ARMATURE ASS'Y 240V INC. 17,18,20,21	1	
020	267806-1	WASHER 9	1	
021	211092-6	BALL BEARING 629DDW	1	
022	450672-5	BRACKET	1	
023	265995-6	TAPPING SCREW 4X18	4	
024	241673-2	FAN 88	1	
025	267164-5	FLAT WASHER 15	1	
026	188579-2	SKIRT L/R SET INC. 28	1	
027	265995-6	TAPPING SCREW 4X18	2	
028	188579-2	SKIRT L/R SET INC. 26	1	
029	318304-9	BEARING BOX	1	
030	211228-7	BALL BEARING 6202DDW	1	
031	424131-5	BRAKE RING	1	
032	318303-1	BEARING BOX COVER	1	
033	253739-6	FLAT WASHER 4	1	
034	911128-8	PAN HEAD SCREW M4X16	1	
035	743081-8	PAD 123	1	
036	911128-8	PAN HEAD SCREW M4X16	3	
037	631832-0	CONTROLLER	1	
A01	135246-0	DUST BOX ASSEMBLY INC. A02-A05	1	
A02	450770-5	DUST BOX	1	
A03	450769-0	DUST NOZZLE	1	
A04	424144-6	RUBBER SLEEVE	1	
A05	232246-2	LEAF SPRING	2	
A06	794544-7	ABRASIVE DISC 125 #120	1	
A07	*****	*****	***	*****
A08	808281-8	BO5031K PLASTIC CASE LABEL	1	

SERVICE DRAWING

MODEL NO. BO5031

